

This cap attaches various masturbators to your VacuGlide including those made by Autoblow and Fleshlight.

IMPORTANT: after 3d printing your cap, you **MUST** install a rubber O ring onto the end of the threads of your stroker and tighten down the 3d printed cap onto the O ring.

The size is this: https://www.theoringstore.com/store/index.php?main_page=product_info&cPath=367_23_25&products_id=1207

You must also remove the small silicone valve from the top of your VacuGlide's cap, and install it onto the 3d printed cap during use. Your VacuGlide came with 2 extra silicone valves (hopefully you did not throw them away) making it convenient for you to leave one permanently installed on your cap.

We offer on autoblow.com a silicone pressure fit cap that is universal and fits any stroker regardless of threads.

Explainer video here: <https://autoblowme.com/vacuglide/vacuum-cap>