

These are the files for the VacuGlide milking mount. To use the milking mount, you simply assemble these pieces, and then you also need to buy additionally a piece of double sided velcro, between 24-26 inches long. The Velcro is used to attach the bottom mount onto your VacuGlide machine.

Once the mount is secured, you can use it with your existing hose and stroker, or better, you can use it to hang an Autoblow stroker or Fleshlight from the horizontal part (using a vacuum cap) above your penis when laying down.

A video showing how this works is here: <https://autoblowme.com/vacuglide/mounts>